

2-Stage Whole House Water Purification System (3/4" Port)

Pre-Installation Guidelines for the 2-Stage Whole House Water Filtration System:

Water Purification System (WPS) Connection: Connect the Water Purification System (WPS) directly to the cold water supply pipe. Ensure a secure and proper connection to maintain the system's functionality.

Sunlight Exposure: Avoid placing the Water Purification System (WPS) under direct sunlight. Choose an installation area that provides shade or protection from direct sunlight to prevent potential damage.

Avoid Damage-Prone Areas: It is crucial to install the Whole House Filter in locations where potential leaks could cause damage. Select an installation area away from sensitive items, electrical components, or areas susceptible to water damage.

Protection from Freezing Temperatures: Avoid installing the system in areas where temperatures can drop below freezing. Freezing temperatures can lead to water expansion, may cause cracks or leaks. Select a location that remains protected from extreme cold.

Water Temperature and Flow Rate: Ensure that the water temperature ranges from a minimum of 40°F to a maximum of 100°F.

The flow rate for the system is between 1 and 10 gallons per minute (GPM), with a working pressure of 20-80 psi. Install a water hammer arrester if necessary to address any sudden spikes in water pressure.

Prepare for Installation: Create a list of all plumbing fittings and tools needed to complete the installation. Consider acquiring screws or bolts to mount the WPS on the wall, as they are not included in the package. Note that screws/bolts and pipe unions are not provided with the system.

Water Shut-Off: Turn off the water supply while installing the Water Purification System (WPS). This ensures a safe and controlled installation process.

Electricity to Water Heater: Turn off the electricity to the water heater during the installation. Once the WPS is installed and pressurized, turn on a few hot and cold faucets to allow any trapped air in the pipes to escape. Afterward, turn the electricity back on for the water heater.

Proper Application of Teflon Tape: Use Teflon tape on threaded fittings to ensure a tight seal. Avoid using excessive layers of tape.

Inlet and Outlet Markings: Take note of the inlet and outlet markings on the system. Remember that the sediment filter (stage 1) is the first stage on the WPS, which is important for proper installation.

Compliance with Codes: Follow all local plumbing codes and building regulations to ensure a safe and compliant installation process. By following these pre-installation guidelines and adhering to local codes, you can ensure the successful and effective installation of the 3-Stage Whole House Water Filtration System.

USE A LICENSED PLUMBER TO INSTALL THIS PRODUCT.

Installation:

1. Mark the inlet and outlet sides of the Water Purification System (WPS).

If you prefer a wall-mounted installation and the water flow is in the opposite direction, do not flip the WPS over.

Instead, unscrew the metal bracket attached to the WPS, flip it, and reinstall.

2. Turn off the main line shut-off valve in the house.

3. Open a few faucets in the house to drain the lines.

4. Place the WPS on the main water supply line where it enters the house, after the main shut-off valve for the whole house but before the pipes branch off into multiple directions.

You may choose to locate the WPS after the branches to the inside and outside plumbing, depending on your preference for filtered water.

5. Measure, cut, and remove a section of the main incoming water line near the installation point of the WPS.

When determining the length of the pipe to cut, account for the filter width, shut-off valves, union fitting, and bypass valve. Allow the line to drain thoroughly. Smooth the newly cut ends to avoid jagged points or edges.

The WPS should be located in a dry, level area and protected from freezing.

6. Install shut-off valves on both sides of the WPS for future easy servicing.

7. Securely mount the WPS using the mounting bracket and bolts (or heavy-duty screws). Ensure the WPS is level.

If you choose not to use a wall-mounted installation, provide extra support for the pipes where the WPS is installed.

8. Fit together the pipe union and shut-off valve, using a small amount of plumbing tape on the threads.

Excessive use of plumbing tape can cause cracks on the housing cap or valves. To ensure a proper seal, wrap the threads with 4–15 layers of Teflon tape (depending on the tape's thickness and fitting size), then apply a light coat of Blue Monster Thread Sealant or another equivalent brand for added leak protection.

For best results, we recommend using our 3/4" male × 3/4" male NPT nipples, which include O-rings for extra sealing performance and compatibility with all standard whole-house filter housings.

9. Simultaneously fit together the shut-off valve and WPS (IN inside). Fit the pipe union to the shut-off valve on the OUT side.

10. Join the pipe union and pipe. Tighten all connections of the installed WPS.

Turning Water Back On:

Slowly turn the water back on. In a few minutes, the sound of water entering the WPS will stop. After the WPS is installed, it is necessary to thoroughly flush the system. To do this, open the nearest COLD water faucet (do not use a hot water faucet)

Water flow



that holds the red button. Turn the screw 360 degrees clockwise.
Repeat if necessary. The adjustment screw is located inside the cap.

To access this area, shut off the water supply using the valves,
remove the housing part, and adjust the pressure release screw.
If the screw is overtightened, the red button (pressure release) will not work.

If needed, slightly release or turn the screw counterclockwise to make the button work.
Tip: You can leave only one button working to release pressure.



Parts required (not included):

- hex nipples or pipe nipples
- pipe union
- pipe hangers (if WPS installed without using wall mounted bracket)
- pressure gauge

Filter Change Instruction

We recommend to change filters every 3-6 months.

1. Turn off the water supply to the WPS from the inside. Open a nearby faucet to lower the water pressure (wait for a couple of minutes).
 2. Press the Red Button (Pressure Release Button).
 3. Unscrew the housing from the cap using a filter wrench.
 4. Remove and discard the old filter cartridges.
 5. Scrub the housing and cap with warm water using a sponge. Rinse all parts thoroughly with water.
 6. Inspect both the inside and outside of the housing for any signs of damage. If needed, lubricate the O-ring with clean silicone grease. Avoid using petroleum jelly. Ensure that the O-ring is properly seated inside the housing.
 7. Remove the filter packaging and insert the new filter cartridges into the housing in the specified order as written on the filter housing.
 8. Fit the bottom of the housing into the cap and hand tighten it. Then, use the filter wrench to securely tighten it.
 9. Close any open faucets and slowly turn on the water supply.
 10. Open the valves on the inside and outside. Carefully inspect for any leaks. If you find a leak, you will need to shut off the water again, remove the housing, and check if the O-ring is seated properly.
 11. Flush the WPS by running a few cold water faucets for a couple of minutes. The new cartridges may contain some carbon dust and air bubbles, which will dissipate in a few days. We recommend checking the WPS for any signs of leaks within the next 12 hours.
- Tip: If you encounter difficulty unscrewing the housing, use an extension (like a pipe) to gain more leverage on the wrench.
Be careful not to apply excessive force, as it may cause the housing to crack.

Parts & Replacement Filter Sets

You can purchase replacement filter set on Amazon.com or MyWaterClub website. Simply enter the ASIN number or perform a simple search on Amazon to find them.

	Amazon ASIN #	MyWaterClub.com
1 Year Replacement Filters Set with Premium Coconut Carbon Block (8 pcs set)	B0DHB2K3DX	SCBCO-1Y
2 Year Replacement Filters Set (16 pcs set)	B0DH9YFVP4	2YDUAL
Housing (replace every 3 years)	B07JYPRQX6	HOUSING34
Gasket	B01MG88IZG	GASKET34

[Scan to find your replacement filter sets or parts:](#)



ONE YEAR LIMITED WARRANTY

What your warranty covers:

Our water purification systems are warranted to the original owner to be free of defects in material and workmanship from the date of manufacture for one year as follows:

- Manufacturer will, within one year of purchase, replace the defected parts (excluding filters) at no charge.
- The replaceable filters are not warranted since the service life of replaceable filter varies with local water conditions and thus not warranted.

Conditions of Warranty:

- System must be maintained and serviced with the manufacturer original replacement parts and filters. The performance of your drinking water system is directly related to the conditions of the water been treated and the particular application in which it is used. Therefore, manufacturer's liability is limited to the cost of repair of the WPS.